

SILVER TRAP MESH RELOADABLE CANISTERS

(Cat. #s: ST-MR4C, ST-MR6C, ST-MR10C, ST-MR20C & TRC-200-3-GF)

INSTALLATION INSTRUCTIONS

1. Locate the **Silver Trap Mesh Reloadable Canister** in close proximity to the drain or waste containment unit (based on local discharge regulations).
2. Remove packing material wrapped around core and discard.
3. Place core upright and insert the open pipe end of tee assembly into the outlet slip fitting.
4. Snap lid on to canister.
5. Screw the black threaded fittings clockwise into the spin welds labeled "INLET" and "OUTLET" on the bucket.
6. Connect ½" or ¾" ID tubing from the processor's fixer overflow to the Canister INLET port.
7. Connect ½" or ¾" ID tubing from the Canister OUTLET port to a second canister, an EPAN Chamber, the drain or waste containment unit (based on local discharge regulations).
8. The **Silver Trap Mesh Reloadable Canister** can be carefully rinsed under slow running water. The canister can then be carefully decanted of liquid before shipping them safely for refining and recycling. A coffee filter can effectively be utilized to drain the canister for shipping. Simply include the filter media inside the canister. In addition, absorbent material, such as sawdust, may be added to the drained canister to meet special "no liquids" shipping rules or simply allow the canisters to dry before shipment.
9. For additional information on disposal refining, please call 1-262-334-3000 or visit our website at www.silverprofit.com.

CORE REPLACEMENT

(Cat. #s: ST-MR4C-R, ST-MR6C-R, ST-MR10C-R & ST-MR20C-R)

1. Remove the new core from the replacement/shipping container and set aside.
2. Remove the outlet tube assembly from the used core center.
3. Carefully lift the bag containing the core out of the canister, drain and place in the replacement/shipping container.
4. Place the bag containing the new core into the canister.
5. Replace outlet tube assembly into new core and connect to outlet port.
6. Replace lid.

COPYRIGHT 2001-Revision Edition Date: August, 2011



ENVIRONMENTAL RECLAMATION, Div.

825 Schoenhaar Dr • West Bend, WI 53090-2633 USA
P.O. Box 835 • West Bend, WI 53095-0835 USA
262-334-3000 • Fax 262-334-6222 • www.silverprofit.com

