

Standard Steel Wool Silver Recovery Bucket



Gravity Feed

SSWB-5-GF

SSWB-3-GF

Metered Pump

SSWB-5-EP

SSWB-3-EP

High quality steel wool metallic replacement silver recovery buckets from the world-renowned leader in Silver Recovery Equipment!

These units are perfect for the cost conscious customer that wants to retrieve the majority of their silver and be in compliance with the silver regulations within their community. We offer the commonly used gravity feed model in a 4.25- gallon unit (SSWB-3-GF) and 5.28-gallon unit (SSWB-5-GF). We also offer a unique Metered Pump model in a 4.25-gallon unit (SSWB-3-EP) and 5.28-gallon unit (SSWB-5-EP). Both models and sizes are for primary recovery or electrolytic back-up use.

The unique EP (Meter Pumped) Model is specifically designed for all pumped applications. Unlike other steel wool buckets, the EP Model, does not have an automatic internal bypass, which simply allows pressurized pumped solution to completely bypass the steel wool catalyst. Model EP is the proper choice for this application.

To receive the maximum benefit from USI's Standard Steel Wool Buckets, it is recommended to use two units in series, and rotate them forward when maximum capacity is met.

Catalog Number	Height	Diam.	Inlet-Outlet Height	Media Weight	Fluid Size	Potential Silver Cap.*	Max. Vol. Cap.* Primary/Secondary	Max. Flow Rate*
SSWB-5-GF SSWB-5-EP	16"	12"	12.5"	8 lbs.	5.28 gal.	100 t.o.	250 gal./625 gal.	300 ml/min.
SSWB-3-GF SSWB-3-EP	12"	12"	8.75"	4 lbs.	4.25 gal.	60 t.o.	150 gal./375 gal.	200 ml/min.

*Performance results vary depending on solution volume, type, brand and mix dilution rates as well as silver concentrations of solutions utilized.



Please call 1-262-334-3000 for more info.

ENVIRONMENTAL RECLAMATION, DIV.

P.O. Box 835, West Bend, WI 53095-0835 U.S.A.

Phone 1-262-334-3000 • Fax 1-262-334-6222 • Web: www.silverprofit.com

SILVERPROFIT.COM

You can find out more about us & our products! Log on to www.silverprofit.com